



Comparison of different sampling methods in hot and diluted flue gas - Preliminary results -


09th November 2022, Kuopio, Finland

Claudia Schön, Hans Hartmann, Elisabeth Rist

Content

- Experimental setup at TFZ
- Log wood stove
 - Procedure and fuels
 - Comparison of TPM sampling methods
- Pellet stove
 - Procedure and fuels
 - Comparison of TPM sampling methods

Experimental setup at TFZ



- Comparison of:
 - Heated filter
 - ENPME
 - Porous tube
 - Full flow dilution
- Investigation of:
 - TPM sampling methods
 - EC/OC/Salts and oxides on filter
- Same sampling duration

Log wood stove – Procedure

- All air inlets at log wood stove are open prior ignition
- 1st TPM measurement = ignition (from top or bottom)
- Intermediate batch at nominal load to change filters
- 2nd TPM measurement = nominal load (2.2 kg)
- Intermediate batch at nominal load to change filters (full load)
- 3rd TPM measurement = nominal load (2.2 kg)
- Intermediate batch at partial load to change filters (partial load)
- 4th TPM measurement = partial load (1.4 kg with 2 logs)
- Recharging of stove always at 4 % CO₂
- All results refer to 13 % O₂



Log wood stove – Fuels

- Beech log wood (3 pieces)



- Ignition with beech logs and small spruce pieces (always)
- Ignition aid: wax-wood wool blocks




- Coffee briquettes (4 pieces)




Parameter	Coffee briquette
Ash content	1.47 w-%
C	53.8 w-%
N	1.81 w-%
K	4140 mg/kg
Si	950 mg/kg
Ca	1430 mg/kg

Log wood stove – Gaseous emission




PA – primary air, bottom – ignition from bottom, top – ignition from top,
 NL – nominal load, PL – partial load

Log wood stove – Organic gaseous carbon emission




PA – primary air, bottom – ignition from bottom, top – ignition from top,
 NL – nominal load, PL – partial load

Log wood stove – TPM emission in undiluted (hot) flue gas




Log wood stove – TPM emission in diluted flue gas




PA – primary air, bottom – ignition from bottom, top – ignition from top,
 NL – nominal load, PL – partial load
 IC – inorganic carbon, EC – elemental carbon, OC – organic carbon

Log wood stove – TPM emission and its composition – Beech



HF – heated filter, PT – porous tube, DT1 – dilution tunnel 1, DT2 – dilution tunnel 2
 IC – inorganic carbon, EC – elemental carbon, OC – organic carbon

Log wood stove – Comparison of sampling methods




Log wood stove – Summary

- Highest emissions during ignition batch
- ENPME underestimates TPM emission slightly by 8 % compared to heated filter method (same sampling duration!)
- Clear increase in TPM emission if flue gas is diluted:
 - Porous tube by factor of 2
 - Dilution tunnel by factor of 1.4


Pellet stove

- 6 kW drop down pellet stove
- Automatic cleaning every hour (not measured)
- 30 minutes measurement (5 replications)
- Nominal load and partial load


Parameter	Unit	Spruce	Beech
Moisture content	w-%, d	7.7	6.2
Ash content	w-%, d	0.37	0.63
Bulk density	kg/m ³ , ar	703	691
K content	mg/kg, d	402	1130
Si content	mg/kg, d	677	1260



Pellet stove – Gaseous emission




Pellet stove – Composition of TPM emission



HF – heated filter, PT – porous tube, DT1 – dilution tunnel 1, DT2 – dilution tunnel 2
 NL – nominal load, PL – partial load
 IC – inorganic carbon, EC – elemental carbon, OC – organic carbon

Pellet stove – Comparison of sampling methods



Pellet stove – Summary

- Beech wood pellet combustion caused higher emissions compared to spruce
- ENPME detected slightly lower TPM emission by 7 % → in agreement with log wood stove trials
- Clear increase in TPM emission if flue gas is diluted:
 - Porous tube and full flow dilution tunnel by the factor of 1.2 to 1.25
 - → lower TPM increase during pellet combustion compared to log wood stove

Thank you for your Attention!



Claudia Schön
Department Solid Biofuels
Technology and Support Centre
in the Centre of Excellence for Renewable Resources (TFZ)

Schulgasse 18

94315 Straubing

Tel.: +49 9421 300-152

Fax: +49 9421 300-211

claudia.schoen@tfz.bayern.de

www.tfz.bayern.de

Log wood stove – Influence of filter treatment

